

INSTALLATION AND ASSEMBLY INSTRUCTIONS

CURV - FLOW

WARNING: Failure to follow instructions could result in damage to product and void warranties!
WARNING: Risk of fire or electrical shock. Disconnect power before installing or servicing.
WARNING: Verify the existing input voltage and ensure it matches input rating on luminaire's product label, located on inside of access cover.
WARNING: Before proceeding, read all instructions carefully to ensure proper and safe installation.
IMPORTANT: This product must be installed in accordance with the applicable installation code by a licensed electrician, familiar with the construction and operation of the product and the hazards involved.

1. DRIVER BOX

2. CANOPY

3. END CAP

4. PENDANT HARDWARE

5. CEILING / WALL MOUNTED BRACKET

6. WALL MOUNTED

7. AL-PROFILE

8. SILICONE DIFFUSER

9. CONNECTORS

10. FASTENING

Driver box for pendant installation

Canopy for pendant

End cap for straight-through cable

End cap

Bracket for wall mounted / ceiling mounted

Tool

Universal male and female connector

Straight connector

Hexagonal screw driver

A suspension point should be installed at approximately 31.5-inch intervals.

1. CONTINUES RUN ASSEMBLY

3. Electrical connection

4. INSTALL SILICONE DIFFUSER

Hexagonal screwdriver

No front/back orientation required

One side first

Then another side

First, buckle one side of the silicone diffuser to a length of about 20-32in. Then, fasten the other side. For the curved profile, first buckle the outer curved side, then the inner curved side.

5. INSTALL ENCAPS

6. DRIVER BOX

7. CANOPY

1. Insert Anchors: Tap the expansion tubes into the drilled ceiling holes.

2. Mount Bracket: Secure the bracket and wire locker to the ceiling using self-tapping screws.

3. Attach Pendant Head: Screw the pendant head directly into the wire locker.

4. Route Cables: Pass the wiring and suspension cables through the pendant box.

5. Place Driver: Install the LED driver securely into the mounting bracket.

6. Secure Box: Fix the pendant box to the bracket using self-tapping screws.

1. Anchor into ceiling.

2. Fix bracket onto ceiling by self-tapping screw.

3. Cable pass through Female wire locker → Canopy → Male wire locker.

4. Fix canopy on bracket by fixed screw.

8. PENDANT HARDWARE

9. CEILING OR WALL MOUNTED

10. WALL MOUNTED

1. Install anchors into the ceiling.

2. Fix the davit onto ceiling.

3. Screw the pendant head into davit.

4. Put the square-head into the wire locker.

5. Install one side of the square-head into profile.

6. Install another side of the square-head into profile.

1. Insert the bracket horizontally into the profile.

2. Rotate the bracket to align it vertically with the profile.

3. Fix the screw

4. Knock the expansion anchors into the ceiling.

5. Fix the bracket to the ceiling.

Wall mounted

4.2 Knock expansion tubes and self-tapping screw into ceiling

5.2 Self-tapping screw goes through the bracket big circle part first. Move it to the narrow part