




INSTALLATION AND ASSEMBLY INSTRUCTIONS

RF-SERIES

WARNING: Failure to follow instructions could result in damage to product and void warranties!

WARNING: Risk of fire or electrical shock. Disconnect power before installing or servicing.

WARNING: Verify the existing input voltage and ensure it matches input rating on luminaire's product label, located on inside of access cover.

WARNING: Before proceeding, read all instructions carefully to ensure proper and safe installation.


IMPORTANT: This product must be installed in accordance with the applicable installation code by a licensed electrician, familiar with the construction and operation of the product and the hazards involved.

RECESSED SPRING BRACKET




RECESSED:


1. RF-RB 2. RF-RBS 3. RF-RBA




1. Create cut outs, refer to shop drawing sheet for dimensions



2. Fix spring brackets using screws




3. Insert Fixture Holding clips in upright position, release clips when in the ceiling




RECESSED

RECESSED:



1.Repeat step 1 (create cut outs)



2.Remove end caps and diffuser



3.Insert fixture into the ceiling and fix bracket using screws



4. Connect power according to wiring diagram




L: Brown
N: Blue
⊕: Green
D+: Purple
D-: Gray




CONTINUOUS RUN ASSEMBLY

CONTINUOUS RUN ASSEMBLY:


1. EXTRUSION 2. END CAP 3. DRIVER 4. DIFFUSER 5. CONNECTING PLATES




1.Remove end caps and diffuser




2.Connect extrusions using connectors and screws



3. Replace the diffuser



4.Connect power according to wiring diagram



L: Brown
N: Blue
⊕: Green
D+: Purple
D-: Gray

